



When to Reset Your Device


Here's a quick guide on resetting your products back to factory settings in the event you move out of your home.

WHEN SHOULD A PRODUCT BE RESET?

- Moving out and leaving products for the next resident
- After changing your Wi-Fi® network name or password
- When you get a new router and don't keep your original Wi-Fi® network name and password
- If your product was deleted from the iDevices Connected app
- If you're switching from Android to iOS or iOS to Android and your product does not sync automatically


⚡ DIMMER SWITCH + ⚡ WALL SWITCH

1. Press and hold the Pairing Setup Button **6** for 10 seconds until LED blinks red.
2. The LED should change to solid purple after the reset is complete.




⚡ WALL OUTLET

1. Press and hold the **1** OR **2** button for 10 seconds until the LED flashes red.
2. The LED on the iDevices Wall Outlet will rapidly flashing blue which means Wall Outlet is reset and waiting to be re-paired.




🌡️ THERMOSTAT

1. On the face of the Thermostat, tap the ⚙️ button
2. Scroll to "Setup" using the ⬆️ and ⬆️ arrows, tap the ⚙️ again to select "Setup"
3. Scroll to "Reset," tap the ⚙️ again to select "Reset"
4. Press and hold the ⚙️ button for 10 seconds until the Thermostat says "Restored"
5. The Thermostat will restart and display the "Welcome!" screen



DELETING A PRODUCT FROM THE CONNECTED APP

1. Select the product name
2. Select "Edit" to the right of the name
3. Scroll down and select "Delete"
4. Confirm by choosing "Delete Accessory"



iDevices is a proud member of the Hubbell family.